

UPRIGHT MOUNT FRAME INSTALLATION

The Upright Frame can be mounted in several ways. They can be mounted as a single frame with a post on each side, a line of frames, or a cluster of frames. The frames attach to a customer supplied wood posts with lag screws (provided). With an additional bracket, you can have a cluster of 3, 5 or more frames. Special configurations may require additional brackets, so talk to us about your design. You can even use these frames back-to-back for a 2-sided exhibit (requires 6" posts). Signs are easily installed by removing the top rail of the frame, inserting the sign, and replacing the top rail.

TOOLS NEEDED: hammer, level, tape measure, socket set and crescent wrench or open ended wrench set, drill and 3/8" bit, allen key set (5/32"), drop cloth or protective sheeting, circular saw for cutting wood posts.

To mount your frame to the wood posts: Lay one post on a flat surface and align the front edge of the frame flush with the front edge of the wood post. The top edge of the frame (removable edge) should be flush with the top edge of the posts. Drive the lag screws through the holes in the side of the frame into the post. Repeat for all holes making sure the frame is aligned with the post. Repeat with the second post, having a helper support the first post during the attachment of the second post. Place the posts in the ground according to your area's requirements. Multiple frame units may have special installation instructions.

To install your sign or graphic panel, use a 5/32" allen key, remove the two bolts from the underside of the top frame edge. Slide off the top of the frame and slide in your graphic panel. Replace the top rail and tighten the screws with your allen key.